for Pharma doors

Page 1 of 1

INSTALLATION INSTRUCTIONS FOR PLASCORE SNOW WHITE TOUCH UP PAINT (FOR DOORS AND OTHER POWDER COATED **SURFACES, PAINT PART #41708D)**

Instructions available in Spanish

- 1. Paint Part# 41708**D** is a glossy Snow White epoxy touch up paint to be used on doors and other snow white epoxy powder coated parts.
- 2. Paint Part# 41708**D** is a two part epoxy composed of paint 41708**D**-A, and converter #41708**D**-B.
- 3. Add contents of container 41708D-B to contents of container 41708D-A and mix thoroughly.
- 4. Allow 15 minutes prior to applying.
- 5. Apply with brush, roller, airless spray, or air spray to achieve desired finish.
- 6. It may be necessary to apply bondo to dents or chipped paint to achieve a smooth finish. (Not provided by Plascore)
- 7. See attached data sheets for additional information.

(End of Section)