



INSTALLATION INSTRUCTIONS FOR PLASCORE SNOW WHITE TOUCH UP PAINT (FOR WALLS AND OTHER UPVC COATED SURFACES, PAINT PART #41708W)

Instructions available in Spanish

1. Paint Part# 41708W is a Snow White epoxy touch up paint to be used on walls and other UPVC coated parts.
2. Paint Part# 41708W is a two part epoxy composed of paint 41708W-A, and converter #41708W-B.
3. Add contents of container 41708W-B to contents of container 41708W-A and mix thoroughly.
4. Allow 15 minutes prior to applying.
5. Apply with brush, roller, airless spray, or air spray to achieve desired finish.
6. It may be necessary to apply bondo to dents or chipped paint to achieve a smooth finish. (Not provided by Plascore)
7. See attached data sheets for additional information.

(End of Section)